## **RUEP: Electro-pneumatic relay**

Used for on/off or change-over switching operations in electro-pneumatic control systems. For control-pressure and supply-pressure lines of  $6 \times 1$  mm. Conforms to the regulations on pressure equipment (97/23/EG Art. 3.3).

Valve body of brass; valve disc with soft sealing of FPM (Viton); solenoid-activated valve; coil is enclosed in synthetic resin; a.c. connection with rectifier integrated within the plug; earth terminal inside the plug; screw terminals for wire of up to 1.5 mm²; cable screw fiting for cable of 6...7 mm diameter; compressed-air connection on the upper part of the valve, G ½ A male thread; suitable for mounting on either wall or rail (C EN 50024 or EN 50022, see accessories) in a location which offers some protection against casual physical contact, e.g. in a cabinet.

Туре	Flow rate <sup>1)</sup> m <sup>3</sup> n/h 6.3 6.3		Connector thread	230 V~ 24 V~ <sup>2)</sup>	Weight kg 0.34 0.34
RUEP 5 F001 RUEP 5 F002			Rp 1/8 Rp 1/8		
Control voltage	230 V~ 24 V~	± 15%, 5060 Hz ± 20%, 5060 Hz		le ambient temp.	055 °C < 90 %rh
Power consumption		5 W (5.5 VA)	Degree of	fprotection	IP 65 (EN 60529)
Permissible pressure or differential pressure 1.7 bar Leakage rate ( $\Delta p = 1$ bar) 0.6 l/h Permissible duty cycle 100%		0.6 l/h		on diagram n drawing tructions	A04522 M04531 MV 505371





#### **Accessories**

0274469 000\* Screw-type bracket of polyamide with R 1/8 male thread

0277717 000\* Screw fitting of polyamide with R 1/8 male thread

0296931 000\* Adaptor with female thread Rp 1/8

**0296936 000\*** Fixing bracket for rail EN 50022–35  $\times$  7.5 and 35  $\times$  15

0296937 000\* Fixing clip for rail C EN 50024-C 20

0296938 000\* Bracket for wall mounting

0381140 001\* Screw fitting of polyamide with Rp 1/8 female thread

- Dimension drawing or wiring diagram are available under the same number
- 1) Flow of air at 1 bar with respect to atmosphere
- Also suitable for 24 V-,  $\pm$  20%

#### Operation

The alternating current connected to the unit is converted by the integrated rectifier into d.c. for the solenoid


Solenoid energised: passage A-P open
A-R closed
Solenoid de-energised: passage A-R open
A-P closed

## **Engineering and fitting notes**


Because of the self-heating properties of the electropneumatic relay, especially in panels at the upper connector R, the material used for the plastic tubing should be suitable for use in temperatures of at least 80 °C (e.g. polyamide).

Do not touch the relay while it is in use or just after it has been switched off.

# Wiring diagram



#### **Dimension drawing**



#### **Accessories**

